



# Replacing the SSD

Written By: Felice Suglia





## TOOLS:


- [Phillips 0 Screwdriver](#) (1)
-

## Step 1 — Battery




- Unlock the latch for fixing the battery to the right.
- Unlock the fixing bolt from the battery to the left.
- Remove the battery pack from the slot.

## Step 2 — Access Components 2





- Using the Philips screwdriver # 0, unscrew the 2 screws of the top cover
- Check marks indicating the direction in which to remove the cover.
- Remove the bottom cover by pulling it in the direction markers.

## Step 3




- Appear then the other components of the Laptop.

## Step 4 — SSD



- Here SSD
- Unscrew the screw securing the SSD using the Philips screwdriver # 0.
- Remove the SSD.

## Step 5



- Here the SSD out of the slot.

Pour le remontage, suivre les instructions dans l'ordre inverse.

This document was last generated on 2017-06-17 06:33:21 PM.